

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
1196	RECORDING PAPER	For 9442 (10 rolls)	5467	6451,06
2103H	METER RELAY			
2103HL	METER RELAY			
2103L	METER RELAY			
2104H	METER RELAY			
2104HL	METER RELAY			
2104L	METER RELAY			
3008	MULTI TESTER			
3030-10	MULTI TESTER			
3120	VOLTAGE DETECTOR			
3126-01	PHASE DETECTOR	With fuse(700V)		
3129	PHASE DETECTOR			
3129-10	PHASE DETECTOR			
3143	EARTH HiTESTER	With 9265,9216,9338		
3151	EARTH HiTESTER			
3153	AUTOMATIC INSULATION/WITHSTANDING HiTESTER			
3157-01	AC GROUNDING HiTESTER			
3159-02	INSULATION/WITHSTANDING HiTESTER	220V Power Supply		
3169-20	CLAMP ON POWER HiTESTER			
3169-21	CLAMP ON POWER HiTESTER	With D/A output		
3174	AC AUTOMATIC INSULATION/WITHSTANDING HiTESTER			
3193-10	POWER HiTESTER			
3194	MOTOR/HARMONIC HiTESTER	Input units are sold separately		
3197	POWER QUALITY ANALYZER	Clamp on Sensor is sold separately		
3237	DIGITAL HiTESTER	With RS-232C		
3237-01	DIGITAL HiTESTER	With RS-232C,GP-IB		
3238	DIGITAL HiTESTER	With RS-232C		
3238-01	DIGITAL HiTESTER	With RS-232C,GP-IB		
3239	DIGITAL HiTESTER	With RS-232C		
3239-01	DIGITAL HiTESTER	With RS-232C,GP-IB		
3244-60	CARD HiTESTER	With Case		
3245-60	SOLAR HiTESTER	With Cap (Red, black)		
3246-60	PENCIL HiTESTER	With Cap (Red, black)		
3255-50	DIGITAL HiTESTER			
3258	SAFETY HiTESTER			
3269	POWER SUPPLY	For 3273,3274,3275,3276		
3272	POWER SUPPLY	For 3273,3274,3275,3276		
3273-50	CLAMP ON PROBE			
3274	CLAMP ON PROBE			
3275	CLAMP ON PROBE			
3276	CLAMP ON PROBE			
3280-10	CLAMP ON HiTESTER			
3280-20	CLAMP ON HiTESTER	RMS		
3281	DIGITAL CLAMP ON HiTESTER	600A		
3282	DIGITAL CLAMP ON HiTESTER	1000A		
3283	CLAMP ON LEAK HiTESTER	RMS		
3283-20	CLAMP ON LEAK HiTESTER	RMS		
3284	CLAMP ON AC/DC HiTESTER	RMS		
3285	CLAMP ON AC/DC HiTESTER	RMS		
3285-20	CLAMP ON AC/DC HiTESTER	No analog-out-put,with R measurement		
3286-20	CLAMP ON POWER HiTESTER	With L9635-01,RMS		
3287	CLAMP ON AC/DC HiTESTER	RMS		
3288	CLAMP ON AC/DC HiTESTER			
3288-20	CLAMP ON AC/DC HiTESTER	RMS		
3290	CLAMP ON AC/DC HiTESTER	Clamp on Sensor is sold separately		
3290-10	CLAMP ON AC/DC HiTESTER	Current integral measurement		
3291-50	CLAMP ON HiTESTER	RMS		
3293-50	CLAMP ON LEAK HiTESTER	RMS		
3332	POWER HiTESTER	For 1p2w		
3333	POWER HiTESTER			

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
3333-01	POWER HiTESTER	With GP-IB		
3334	AC/DC POWER HiTESTER			
3334-01	AC/DC POWER HiTESTER	With GP-IB		
3390	POWER ANALYZER	Clamp on Sensor is sold separately		
3390-10	POWER ANALYZER	Clamp on Sensor is sold separately		
3423	LUX HiTESTER			
3441	TEMPERATURE HiTESTER	Temp. probe is sold separately		
3441-02	TEMPERATURE HiTESTER	Celsius/Fahrenheit selectable		
3442	TEMPERATURE HiTESTER	Waterproof		
3455	HIGH VOLTAGE INSULATION HiTESTER	With 9751-01,-02,-03 (Red,black,blue)		
3481-20	VOLTAGE DETECTOR			
3490	ANALOG MΩ HiTESTER			
3504-40	C HiTESTER			
3504-50	C HiTESTER			
3504-60	C HiTESTER			
3506-10	C METER			
3511-50	LCR HiTESTER	Test fixtures are sold separately		
3554	BATTERY HiTESTER			
3555	BATTERY HiTESTER	For compact storage batteries		
3561	BATTERY HiTESTER	Test Leads are sold separately		
3561-01	BATTERY HiTESTER	Test Leads are sold separately,with GP-IB		
3650	TEMPERATURE LOGGER			
3664	OPTICAL POWER METER	With 9445-02		
3665-20	LAN CABLE HiTESTER			
3853	CARRYING CASE	For 3800s		
3930	HIGH VOLTAGE SCANNER	For 3153		
8423	MEMORY HiLOGGER			
8826	MEMORY HiCORDER	Input units are sold separately,32ch		
8860-50	MEMORY HiCORDER	Input units are sold separately		
8861-50	MEMORY HiCORDER	Input units are sold separately		
8870-20	MEMORY HiCORDER	With 9786,9809		
8910	CAN ADAPTER	For 8841,8826,etc		
8936	ANALOG UNIT	With 8835,8835-01,8841,8842,8860,8861		
8937	VOLTAGE/TEMP UNIT	With 8826,8835,-01,8841,8842,8860,8861		
8938	FFT ANALOG UNIT	With 8826,8835-01,8841,8842,8860,8861		
8939	STRAIN UNIT	With 8826,8835-01,8841,8842,8860,8861		
8940	F/V UNIT	With 8826		
8946	4ch ANALOG UNIT	With 8835-01,8841		
8947	CHARGE UNIT	With 8826,8835,-01,8841,8842,8860,8861		
8948	VOLTAGE/TEMP UNIT	For 8423		
8949	UNIVERSAL UNIT	For 8423		
8956	ANALOG UNIT	For 8860,8861s		
8957	HIGH RESOLUTION UNIT	For 8860,8861s		
8958	16ch SCANNER UNIT	For 8860,8861s		
8959	DC/RMS UNIT	For 8860,8861s		
8960	STRAIN UNIT	For 8860,8861,8862		
8961	HIGH VOLTAGE UNIT	For 8861-50,Max 4units		
8966	ANALOG UNIT	For MR8847s,8847		
8967	TEMP UNIT	For MR8847s,8847		
8968	HIGH RESOLUTION UNIT	For MR8847s,8847		
8969	STRAIN UNIT	For MR8847s,8847		
8970	FREQ UNIT	For MR8847s,8847		
8971	CURRENT UNIT	For MR8847s,8847		
8972	DC/RMS UNIT	For MR8847s,8847		
8973	LOGIC UNIT	For MR8847s,8847		
8995	A4 PRINTER UNIT	For 8860,8861,8860-50,8861-50		
8995-01	A6 PRINTER UNIT	For 8860,8861,8860-50,8861-50		
8996	DIGITAL/PULSE UNIT	For 8423		
8997	ALARM UNIT	For 8423		
9010-50	CLAMP ON PROBE	Out-put: BNC		
9014	HIGH VOLTAGE PROBE	For 3256,3257,3800s		

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
9017	HIGH VOLTAGE PROBE	For 3030-10		
9018-50	CLAMP ON PROBE			
9021-01	THERMISTOR TEMPERATURE PROBE	For 3030-10,3127-10,3128-10		
9032	METAL CONTACT TIP	For FT3405,FT3406,3402,3403,3404		
9033	RUBBER CONTACT TIP	For FT3405,FT3406,3402,3403,3404		
9050	EARTH NETS	For 3124,3150,3151		
9060	TEST LEAD	For 3008s,3125		
9073	RECORDING PAPER	For 8201,8202,8204 (10 rolls)		
9074	RECORDING PAPER	For 8203 (10 rolls)		
9094	OUTPUT CORD	For 3283,3284,3285,3412-50,3423,FT3406,		
9099	CLIP TYPE LEADS	For 3220,3224		
9132-50	CLAMP ON PROBE	AC1000A,BNC terminal		
9140	4-TERMINAL PROBE	For 3511-50,3522-50,3532-50,etc		
9140-10	4-TERMINAL PROBE			
9143	PINCHER PROBE	For 3511-50,3522-50,3532-50,etc		
9143-10	PINCHER PROBE			
9151-02	GP-IB CONNECTOR CABLE	For 3334,etc.		
9165	CONNECTION CORD	For 3271,8852,9268,9269 (BNC-BNC)		
9166	CONNECTION CORD	For 3271,8852,9268,9269 (BNC-Clip)		
9168	INPUT CORD	For 7010,7011,SS7012		
9180	SHEATH TYPE TEMPERATURE PROBE	For 3412,3414,344,3442-02,3803,7015		
9181	SURFACE TEMPERATURE PROBE	For 3412,3414,3441,3442-02,3801,3803,7015		
9182	SHEATH TYPE TEMPERATURE PROBE	For 3412,3414,3441,3442-02,3801,3803,7015		
9183	SHEATH TYPE TEMPERATURE PROBE	For 3412,3414,3441,3442-02,3801,3803,7015		
9184	TEMPERATURE PROBE	For 7010,7011,SS7012		
9195	ENCLOSURE PROBE	For ST5540s,3156,3155-01		
9199	CONVERSION ADAPTOR	For Memory Recorders		
9203	DIGITAL PRINTER	For 8835-01,8808,3560,3540-02,3550,3551		
9209	TEST LEADS HOLDER	For 3280s,3287,3288		
9211	REFLECTIVE TAPE	For FT3405,FT3406,3402,3403,3404		
9212	PERIPHERAL RING	For FT3405,FT3406,3402,3403,3404		
9213	CONTACT ADAPTER	For 3403,3404		
9214	AUXILIARY EARTHING ROD	For 3151		
9215	MEASURING CABLE	For 3150,3151		
9219	CONNECTION CABLE			
9221	RECORDING PAPER	For 8815,8830,8835s,8852 (10 rolls)		
9222	RECORDING PAPER	For 9200,9514 (5 rolls)		
9223	RECORDING PAPER	For 3165,3191 (5 rolls)		
9229	RECORDING PAPER	For 8826,8825 (6 rolls)		
9229-01	RECORDING PAPER(PERFORATED)	For 8826,8825(Perforated) (6 rolls)		
9231	RECORDING PAPER	For 8860-50,8861-50,MR8847,etc. (6rolls)		
9232	RECORDING PAPER	For 3193,8804,8805,8806, etc (10rolls)		
9233	RECORDING PAPER	For 9203,3155-01 (10rolls)		
9234	RECORDING PAPER	For MR8880-20,8807,8808,8420s,etc. (10rol		
9235	RECORDING PAPER	For 8205-10,8206-10 (10rolls)		
9236-01	RECORDING PAPER	For 8205-10,8206-10 (10rolls)		
9237	RECORDING PAPER	For 9670 (4 rolls)		
9242	CONNECTION CORD	For 8961		
9243	GRABBER CLIP	For 8961		
9246	CARRYING CASE	For 3664		
9248	POWER CORD	For 9687		
9249	CARRYING CASE	For 3665-20		
9261	TEST FIXTURE	For 3511-50,3522-50,3532-50		
9261-10	TEST FIXTURE			
9262	TEST FIXTURE	For 3511-50,3522-50,3532-50		
9263	TEST FIXTURE	For 3511-50,3522-50,3532-50		
9265	MEASUREMENT CABLE	For 3143		
9267	SAFETY TEST DATA MANAGEMENT SOFTWARE	For 333Xs,3153,3154,3157,3158,3159,3174		
9268	DC BIAS VOLTAGE UNIT	For 3511,3522-50,3532-50		
9268-01	DC BIAS VOLTAGE UNIT	For 3522-50,3532-50 (HDMI)		
9268-10	DC BIAS VOLTAGE UNIT			

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
9269	DC BIAS CURRENT UNIT	For 3511,3522-50,3532-50		
9269-10	DC BIAS CURRENT UNIT			
9272-10	CLAMP ON SENSOR			
9277	UNIVERSAL CLAMP ON CT	AC/DC 20A (for 3192,3167)		
9278	UNIVERSAL CLAMP ON CT	AC/DC 200A (for 3192,3167)		
9279	UNIVERSAL CLAMP ON CT	AC/DC 500A (for 3192,3167)		
9288	BREAKER PIN	For 9292,9294		
9290-10	CLAMP ON ADAPTER			
9291	CLAMP ON SENSOR	For 3166		
9292	TEST PROBE	For 3451s,3452s		
9293	PIN TYPE EARTH PROBE	For 3451s,3452s		
9296	CURRENT PROBE	For 3157-01		
9297	CURRENT APPLY PROBE	For 3157-01		
9298	CLAMP ON SENSOR	For 3166		
9299	SWITCHED PROBE	For 3154		
9300	CONNECTION CABLE	For 3541		
9318	CONVERSION CABLE	For 8940		
9319	CONVERSION CABLE	For 3273-50,8940		
9320	LOGIC PROBE	For 8800s (exc.8807,8808)		
9320-01	LOGIC PROBE	For 8807,8808,8847,8855,8860s,8870		
9322	DIFFERENTIAL PROBE	For Memory Recorders		
9323	CONVERSION CABLE	For 9320,9321		
9324	POWER CORD	For 9322		
9325	POWER CORD	For 9322		
9326	CONNECTION CORD	For 8205-10		
9327	LOGIC PROBE	For 8847,8855,8860s,MR8847		
9328	POWER CORD	For 9322		
9333	LAN COMMUNICATOR	For 8826,8835-01,8841,8842,8855		
9335	WAVE PROCESSOR	For Memory Recorders (exc.8852,8853)		
9338	CARRYING CASE	For 3143		
9339	CARRYING CASE	For 3196 (soft case)		
9340	CARRYING CASE	For 3196 (hard case)		
9344	CARRYING CASE	For 8205-10,8206-10		
9355	CARRYING CASE	For 3264s,3286,9270,9271,9272		
9371	CARRYING CASE	For 3255,3255-50		
9376	CARRYING CASE	For 3423		
9378	CARRYING CASE	For 3256,3257		
9380	CARRYING CASE	For 7011,SS7012		
9382	CARRYING CASE	For 3550,3555		
9384	CARRYING CASE	For 3451,3452		
9386-01	CARRYING CASE	For 3441,3442,3446-01,3447-01		
9388	CARRYING CASE	For 8835-01, 3155-01		
9390	CARRYING CASE	For 3030-10		
9393	CARRYING CASE	For 3151		
9398	CARRYING CASE	For 3280-10,3280-20,3287,3288		
9399	CARRYING CASE	For 3281,3282,3283,3284		
9400	CARRYING CASE	For 3290,3290-10		
9418-10	AC ADAPTER	For 3167,etc.		
9418-15	AC ADAPTER	For 8807,8808s,8420s,etc.		
9425	CONNECTION CABLE	For 9203		
9436	CONNECTION CABLE	For 3423		
9438	VOLTAGE CORD	For 3166 (3m)		
9440	CONNECTION CABLE	For 3166,3169-20,3169-21 (For EXT. control)		
9441	CONNECTION CABLE	For 3166,3169-21 (For D/A out)		
9442	PRINTER	For 3522-50,3532-50,etc.		
9443-02	AC ADAPTER	For 9442 (For EU)		
9444	CONNECTION CABLE	For 9442		
9445-02	AC ADAPTER	For 3283,3284,3285,3540,9667 (For USA)		
9445-03	AC ADAPTER	For 3283,3284,3285,3540,9667 (For EU)		
9446	CONNECTION CABLE	For 9442		
9447	BATTERY PACK	For 8807,8808s,8420s		

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
9451	TEMPERATURE PROBE	For 3540,3541		
9452	CLIP TYPE LEAD	For 3227,3540,3541,3555,3560,3561		
9453	FOUR TERMINAL LEAD	For 3540,3541,3555,3561,etc.		
9454	ZERO ADJUSTMENT BOARD	For 3560,3561,BT3562,BT3563		
9455	PIN TYPE LEAD	For 3226,3227,3540,3541,3560,3561		
9458	AC ADAPTER	For 3196		
9459	BATTERY PACK	For 3196,3197,3455		
9460	CLIP TYPE LEAD WITH TEMPERATURE SENSOR	For 3540,3550,3551		
9461	PIN TYPE LEAD	For 3155-01,3227,3239,3555,3560		
9465	PIN TYPE LEAD	For 3550,3551,3555,3540,3541,3560		
9465-10	PIN TYPE LEAD	For 3550,3551,3554		
9465-90	TIP PIN	For 9465-10		
9466	REMOTE CONTROL SWITCH	For 3551,3560		
9467	LARGE CLIP TYPE LEAD	For 3550,3551,3554,3561,etc.		
9472	SHEATH TYPE TEMPERATURE PROBE	For 3441,3442,Sheath type		
9472-50	SHEATH TYPE TEMPERATURE PROBE	For 3446-01,Sheath type		
9473	SHEATH TYPE TEMPERATURE PROBE	For 3441,3442,Sheath type		
9473-50	SHEATH TYPE TEMPERATURE PROBE	For 3446-01,Sheath type		
9474	SHEATH TYPE TEMPERATURE PROBE	For 3441,3442,Sheath type		
9475	SHEATH TYPE TEMPERATURE PROBE	For 3441,3442,Sheath type		
9476	SURFACE TYPE TEMPERATURE PROBE	For 3441,3442,Surface type		
9476-50	SURFACE TYPE TEMPERATURE PROBE	For 3446-01,Surface type		
9478	SHEATH TYPE TEMPERATURE PROBE	For IM3533,IM3533-01,IM3590		
9500	4-TERMINAL PROBE			
9500-10	4-TERMINAL PROBE			
9518-01	GP-IB INTERFACE	For 3511,-50,3522,-50,3531,3532-50,-80		
9518-02	GP-IB INTERFASE	For 3157-01		
9540-01	FUNCTION UP DISK	For 8835-01		
9549	FUNCTION UP DISK(POWER MONITOR)	For 8855		
9555-10	SENSOR UNIT	For 9272-10,9709		
9574	INPUT CORD	For 8916(8840,45,46),8944(8851),8945(8853)		
9588	GP-IB INTERFACE	For 3227,3167,3187,3330,3330-01,3560		
9593-01	RS-232C INTERFACE	For 3522-50,3532-50,3532-80		
9593-02	RS-232C INTERFACE	For 3157-01		
9599	MEMORY BOARD	For 8826		
9600	AC/DC DIRECT INPUT UNIT	Factory option for 3193,3194		
9601	AC DIRECT INPUT UNIT	Factory option for 3193,3194		
9602	AC/DC CLAMP INPUT UNIT	Factory option for 3193,3194		
9603	EXTERNAL SIGNAL INPUT UNIT	Factory option for 3193		
9603-01	EXTERNAL SIGNAL INPUT UNIT	Factory option for 3193		
9604	PRINTER UNIT	Factory option for 3193,3194		
9605	HARMONIC/FLICKER MEASURMENTS UNIT	For 3193		
9612	RS-232C CABLE	For 3169-20,3169-21,8420s,8807,8808		
9613	REMOTE CONTROL BOX(SINGLE)	For 3153,3157,3158,3159		
9614	REMOTE CONTROL BOX(DUAL)	For 3153,3157,3158,3159		
9615	H.V.TEST LEAD	For 3174,3173,3159,3158,3153		
9618	CLIP-TYPE LEAD	For 3801,3802,3804,3805,3501		
9624-50	PQA-HiVIEW PRO	For 3196,3197,PW3198		
9625	POWER MEASUREMENT SUPPORT SOFTWARE	For 3166,3168,3169		
9629	CONNECTION CABLE	For 3639,3672		
9630	HUMIDITY SENSOR	For 3630s(1m)		
9631-01	TEMPERATURE SENSOR	For 3630s(Moldedtype,1m)		
9631-02	TEMPERATURE SENSOR	For 3630s(Needletype,1m)		
9631-03	TEMPERATURE SENSOR	For 3630s(Sheathtype,1m)		
9631-04	TEMPERATURE SENSOR	For 3630s(Lugtype,1m)		
9631-05	TEMPERATURE SENSOR	For 3630s(Moldedtype,10m)		
9631-11	TEMPERATURE SENSOR(9631-01,5m)	For 3630s(Moldedtype,5m)		
9631-14	TEMPERATURE SENSOR(9631-04,5m)	For 3630s(Lugtype,5m)		
9631-21	TEMPERATURA SENSOR(9631-01,10m)	For 3630s(Moldedtype,10m)		
9631-24	TEMPERATURE SENSOR(9631-04,10m)	For 3630s(Lugtype,10m)		
9632	CONNECTION CABLE	For 3630s(1m)		
9635-01	VOLTAGE CORD	For 3286,3286-20		



Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
9637	RS-232C CABLE(9pin-9pin/1.8m)	For 3154,BT3560s,etc(9 pin-9 pin,Cross)		
9638	RS-232C CABLE(9pin-25pin/1.8m)	For 3154,BT3560s,etc(9 pin-25 pin,Cross)		
9639	CONNECTION CABLE	For 3674		
9641	CONNECTION CABLE	For 8420s		
9642	LAN CABLE	For 8420s,3390-10		
9650	CLAMP ON SENSOR	For 8205,06		
9651	CLAMP ON SENSOR	For 8205,06		
9657	CLAMP ON LEAK SENSOR	For 3638-20		
9657-10	CLAMP ON LEAK SENSOR	For Memory Recorder,PW3198		
9658	CLAMP ON LEAK SENSOR	For 3638-20		
9660	CLAMP ON SENSOR	For 3169s,3196,PW3198		
9661	CLAMP ON SENSOR	For 3169s,3196,PW3198		
9661-01	CLAMP ON SENSOR	For 2300s		
9664	HD UNIT	For MR8847s,8847		
9665	10:1PROBE	For MR8880-20,MR8847s,8860,8861s,etc.		
9666	100:1PROBE	For MR8880-20,MR8847s,8860,8861s,etc.		
9668	CLAMP ON SENSOR	For 8205-10,8206-10		
9669	CLAMP ON SENSOR	For 3169s,3196,PW3198		
9672	BATTERY PACK	For 9670		
9673	BATTERY CHARGER	For 9670		
9674	RS-232C PACKAGE	For 3446-01,3447-01		
9675	CLAMP ON LEAK SENSOR	For PW3198		
9677	SMD TEST FIXTURE	For LCR Testers		
9678	CONNECTION CABLE	For 3535		
9680-50	HUMIDITY SENSOR	For 3641,3670(1m)		
9680-51	HUMIDITY SENSOR	For 3641,3670(5m)		
9680-52	HUMIDITY SENSOR	For 3641,3670(10m)		
9683	CONNECTION CABLE	For 3390,8423		
9684	DC POWER UNIT	For 8860,8861s		
9687	PROBE POWER UNIT	For 8860,8861s		
9690-01	TERMINATOR(ID1-5)	For 3665-20		
9690-02	TERMINATOR(ID6-10)	For 3665-20		
9690-03	TERMINATOR(ID11-15)	For 3665-20		
9690-04	TERMINATOR(ID16-20)	For 3665-20		
9694	CLAMP ON SENSOR	For 3169-20,21,3196,PW3198		
9695-02	CLAMP ON SENSOR	For 3169-20,21,PW3198		
9695-03	CLAMP ON SENSOR	For 3169-20,21,PW3198		
9696	CARRYING CASE	For 3453,3453-01		
9699	SMD TEST FIXTURE	For LCR Testers		
9700-10	HEAD AMP UNIT	For 3535(Factory option)		
9701	HUMIDITY SENSOR	For 8420-51,8421-51		
9704	CONVERSION ADAPTER	For 9010-50,9018-50,9132-50(BNC-Banana)		
9705	CONVERSION CABLE	For 9272-10,9709,CT6863		
9706	EXTENSION CABLE	For 9272-10,9709,CT6863		
9709	AC/DC CURRENT SENSOR	For 3390,etc		
9709-05	AC/DC CURRENT SENSOR	For PW6001 (500A)		
9709-10	AC/DC CURRENT SENSOR	For 3390-10		
9713-01	CAN CABLE	For 8910,MR8904		
9714-01	LOGIC CABLE	For 8910		
9714-02	LOGIC CABLE	For 8910		
9715-50	MEMORY BOARD	For 8860-50,8861-50		
9715-51	MEMORY BOARD	For 8860-50,8861-50		
9715-52	MEMORY BOARD	For 8860-50,8861-50		
9715-53	MEMORY BOARD	For 8860-50,8861-50		
9718-50	HD UNIT	For 8860-50,8861-50		
9719-50	MEMORY BACKUP UNIT	For 8860-50,8861-50		
9720-01	CARRYING CASE	For 3169-20,3169-21		
9721	RS-232C CABLE	For 3169-20,3169-21		
9723	CARRYING CASE	For 8860s		
9724	CARRYING CASE	For 8861s		
9725	MEMORY HiVIEWER	For 8860s,8861s		
9728	PC CARD 512M			

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
9729	PC CARD 1G			
9730	CARRYING CASE	Holds 3661-20,3662-20,3663-20		
9731	FC CONNECTOR ADAPTER	For 3661-20		
9732	SC CONNECTOR ADAPTER	For 3661-20		
9733	FC CONNECTOR ADAPTER	For 3662-20,3663-20		
9734	SC CONNECTOR ADAPTER	For 3662-20,3663-20		
9738	OPTICAL CONNECTOR CLEANER	For 3661-20,3662-20,3663-20		
9739	SPARE CLEANER	For 3661-20,3662-20,3663-20		
9742	OPTICAL SENSOR	For 3664		
9742-10	OPTICAL SENSOR	For 3664		
9743	OPTICAL SENSOR	For 3664		
9743-10	OPTICAL SENSOR	For 3664		
9750-01	TEST LEAD	For 3455		
9750-02	TEST LEAD	For 3455		
9750-03	TEST LEAD	For 3455		
9750-11	TEST LEAD	For 3455		
9750-12	TEST LEAD	For 3455		
9750-13	TEST LEAD	For 3455		
9751-01	ALLIGATOR CLIP	For 3455		
9751-02	ALLIGATOR CLIP	For 3455		
9751-03	ALLIGATOR CLIP	For 3455		
9753	AC ADAPTER	For 3455		
9754	CLAMP ON NOISE SENSOR	For 3145-20		
9757	CARRYING CASE	For 3291-50,3293-50,FT3432		
9758	EXTENSION CABLE	For 3470		
9759	OUTPUT CABLE	For 3470		
9769	CONVERSION CABLE	For 8969		
9770	PIN TYPE LEAD	For 3239,3541,3561,BT3562,BT3563,etc.		
9771	PIN TYPE LEAD	For 3239,3541,3561,BT3562,BT3563,etc.		
9772	PIN TYPE LEAD	For 3554		
9772-90	TIP PIN	For 9772		
9780	BATTERY PACK	For 8430-20,8870-20		
9782	CARRYING CASE	For 8430-20,8870-20,SS7012		
9783	CARRYING CASE	For MR8847,etc.		
9784	DC POWER UNIT	For MR8847,etc.		
9786	AC ADAPTER	For 8430-20,8870-20		
9790-02	GRABBER CLIP	For L9790(MR8847,8870)		
9790-03	CONTACT PIN	For 8870-20,9790 (Red and black set)		
9791	MOTOR TESTING OPTION	For 3390,3390-10 (Factory option)		
9792	D/A OUTPUT OPTION	For 3390,3390-10 (Factory option)		
9793	MOTOR TESTING & D/A OUTPUT OPTION	For 3390,3390-10 (Factory option)		
9794	CARRYING CASE	For 3390,3390-10		
9804	MAGNETIC ADAPTER	For 9438-50,Red and black		
9804-01	MAGNETIC ADAPTER	For 3169-2x,PW3198,Red		
9804-02	MAGNETIC ADAPTER	For 3169-2x,PW3198,IR4000s,Black		
9809	PROTECTION SHEET	For 8430-20,8870-20		
9812	SOFT CASE	For 8430-20,8870-20		
9830	PC CARD 2G	For 3390,8430-20,8800s,etc.		
BT3562	BATTERY HiTESTER			
BT3562-01	BATTERY HiTESTER	With GP-IB & Analog output		
BT3563	BATTERY HiTESTER			
BT3563-01	BATTERY HiTESTER	With GP-IB & Analog output		
C0106	CARRYING CASE	For FT6031-03 (Standard)		
C0200	CARRYING CASE	For DT4220 Series		
C0201	CARRYING CASE	For DT4250 Series		
C0202	CARRYING CASE	For DT4280 Series		
C0203	CARRYING CASE	For CM4300 Series		
C0204	CARRYING CASE	For DT4280 Series		
C1000	CARRYING CASE	For LR8400s		
C1001	CARRYING CASE	For PW3198,Soft type		
C1002	CARRYING CASE	For PW3198,Hard type		

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
C1003	CARRYING CASE	For MR8880-20		
C1004	CARRYING CASE			
C1005	CARRYING CASE	For PW3360-20		
C1006	CARRYING CASE	For RM3548		
C1007	CARRYING CASE			
C1008	CARRYING CASE	for PW3365-20		
CC-98A	AC MONITOR OUTPUT CABLE	For FT3432,FT3432-20		
CC-98D	DC OUTPUT CABLE	For FT3432,FT3432-20		
-5MRN100	CURRENT TRANSFORMER	100A:5A		
-5MRN120	CURRENT TRANSFORMER	120A:5A		
-5MRN150	CURRENT TRANSFORMER	150A:5A		
CT6500	CLAMP ON SENSOR	For LR5051, 500A AC		
CT6590	SENSOR UNIT			
CT6841	AC/DC CURRENT SENSOR	AC/DC20A		
CT6841-05	AC/DC CURRENT SENSOR	For PW6001 (20A)		
CT6843	AC/DC CURRENT SENSOR	AC/DC200A		
CT6843-05	AC/DC CURRENT SENSOR	For PW6001 (200A)		
CT6844	AC/DC CURRENT SENSOR	AC/DC600A (200 kHz)		
CT6844-05	AC/DC CURRENT SENSOR	AC/DC600A (200 kHz)		
CT6845	AC/DC CURRENT SENSOR	AC/DC600A (100 kHz)		
CT6845-05	AC/DC CURRENT SENSOR	AC/DC600A (100 kHz)		
CT6862	AC/DC CURRENT SENSOR	For 3390,etc. 50A		
CT6862-05	AC/DC CURRENT SENSOR	For PW6001 (50A)		
CT6862-10	AC/DC CURRENT SENSOR	For 3390-10, 50A		
CT6863	AC/DC CURRENT SENSOR	For 3390,etc. 200A		
CT6863-05	AC/DC CURRENT SENSOR	For PW6001 (200A)		
CT6863-10	AC/DC CURRENT SENSOR	For 3390-10, 200A		
CT6865	AC/DC CURRENT SENSOR	For 3390,8940,8951,8971,9555s,9602,etc.		
CT6865-05	AC/DC CURRENT SENSOR	For PW6001 (1000A)		
CT9667-01	FLEXIBLE CLAMP ON SENSOR			
CT9667-02	FLEXIBLE CLAMP ON SENSOR			
CT9667-03	FLEXIBLE CLAMP ON SENSOR			
CT9691	CLAMP ON AC/DC SENSOR			
CT9691-90	CLAMP ON AC/DC SENSOR			
CT9692	CLAMP ON AC/DC SENSOR			
CT9692-90	CLAMP ON AC/DC SENSOR			
CT9693	CLAMP ON AC/DC SENSOR			
CT9693-90	CLAMP ON AC/DC SENSOR			
CT9700	CURRENT PROBE			
CT9701	CURRENT PROBE			
CT9900	CONVERSION CABLE			
CT9901	CONVERSION CABLE			
CT9902	EXTENSION CABLE			
CM4371	AC/DC CLAMP METER			
CM4373	AC/DC CLAMP METER			
DT4211	DIGITAL MULTIMETER			
DT4212	DIGITAL MULTIMETER			
DT4221	DIGITAL MULTIMETER	Minimum order quantity is 5pcs		
DT4222	DIGITAL MULTIMETER	Minimum order quantity is 5pcs		
DT4252	DIGITAL MULTIMETER	Minimum order quantity is 5pcs		
DT4253	DIGITAL MULTIMETER			
DT4254	DIGITAL MULTIMETER			
DT4255	DIGITAL MULTIMETER			
DT4256	DIGITAL MULTIMETER			
DT4281	DIGITAL MULTIMETER			
DT4282	DIGITAL MULTIMETER			
DT4900	COMMUNICATION PACKAGE(USB)	For DT4280 Series		
DT4900-01	COMMUNICATION PACKAGE (USB)	For DT42xx Series		
DT4910	THERMOCOUPLES(K)			
DT4911	TEST LEAD			
DSM-8104				



Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
DSM-8542				
FT3405	TACHO HiTESTER	No output		
FT3406	TACHO HiTESTER	With Analog output & Pulse output		
FT3424	LUX METER			
FT3432	SOUND LEVEL METER			
FT3470-51	MAGNETIC FIELD HiTESTER			
FT3470-52	MAGNETIC FIELD HiTESTER			
FT3700-20	INFRARED THERMOMETER			
FT3701-20	INFRARED THERMOMETER			
FT6031-03	EARTH TESTER			
FT6380	CLAMP ON EARTH TESTER			
HS-1-100	EXTERNAL SHUNT	100A:50mV		
HS-1-150	EXTERNAL SHUNT	150A:50mV		
HS-1-200	EXTERNAL SHUNT	200A:50mV		
HS-1-30	EXTERNAL SHUNT	30A:50mV		
HS-1-300	EXTERNAL SHUNT	300A:50mV		
HS-1-50	EXTERNAL SHUNT	50A:50mV		
HS-1-75	EXTERNAL SHUNT	75A:50mV		
IM3523	LCR METER			
IM3533	LCR METER			
IM3533-01	LCR METER			
IM3536	LCR METER			
IM3570	IMPEDANCE ANALYZER			
IM3590	CHEMICAL IMPEDANCE ANALYZER			
IM7580-02	IMPEDANCE ANALYZER			
IM7583-01	IMPEDANCE ANALYZER			
IM7583-02	IMPEDANCE ANALYZER			
IM7585-01	IMPEDANCE ANALYZER			
IM7585-02	IMPEDANCE ANALYZER			
IM9000	EQUIVALENT CIRCUIT ANALYSIS FIRMWARE	For IM3570		
IM9100	SMD TEST FIXTURE	For IM3523, IM3533s, IM3570, IM3590, 3532-50,		
IM9901	CONTACT TIPS	For L2001 (Standard)		
IM9902	CONTACT TIPS	For L2001 (Option)		
IR4016-20	ANALOG MΩ HiTESTER	500V/100M-ohm		
IR4017-20	ANALOG MΩ HiTESTER	500V/1000M-ohm		
IR4018-20	ANALOG MΩ HiTESTER	1000V/2000M-ohm		
IR4053-10	INSULATION TESTER			
IR4056-20	INSULATION TESTER			
IR4057-20	INSULATION TESTER			
L1000	VOLTAGE CORD	For PW3198,3196		
L2000	4-TERMINAL PROBE	For IM3570,3505,3506		
L2001	PINCHER PROBE	For IM3523,IM3533		
L2100	PIN TYPE LEAD	For BT3562,BT3563		
L2101	CLIP TYPE LEAD	For RM3544s, RM3545s		
L2102	PIN TYPE LEAD	For RM3544s, RM3545s		
L2103	PIN TYPE LEAD	For RM3544s, RM3545s		
L2104	4-TERMINAL LEAD	For RM3544s,RM3545s		
L2105	LED COMPARATOR ATTACHMENT	For RM3544s RM3545s,RM3548		
L2107	CLIP TYPE LEADS	For RM3544s RM3545s,RM3548		
L2200	TEST LEAD	For ST5540,ST5541		
L4930	CONNECTION CABLE SET	For DT4280 Series		
L4931	EXTENSION CABLE SET	For DT4280 Series		
L4932	TEST PIN SET	For DT4280 Series		
L4933	CONTACT PIN SET	For DT4280 Series		
L4934	SMALL ALLIGATOR CLIP SET	For DT4280 Series		
L4935	ALLIGATOR CLIP SET	For DT4280 Series		
L4936	BUS BAR CLIP SET	For DT4280 Series		
L4937	MAGNETIC ADAPTER SET	For DT4280 Series		
L4938	TEST PIN SET	For DT4280 Series		
L4939	BREAKER PIN SET	For DT4200 DMM Series		
L4940	CONNECTION CABLE SET	For DT42xx Series		

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
L6000	OPTICAL CONNECTION CABLE			
L9170-10	TEST LEAD	For 3156,3237,3238,3239,SS7012		
L9197	CONNECTION CORD			
L9198	CONNECTION CORD	For Memory Recorders,Ins. BNC,up to 300V		
L9207-10	TEST LEAD	For 3256,3257-50,3281,3282,3284,3285s,etc		
L9207-30	TEST LEAD	For 3030-10,3127-10		
L9208	TEST LEAD	For 3280s,3287,3288s,etc.		
L9217	CONNECTION CORD	For Memory Recorders		
L9257	CONNECTION CORD	For 8205-10,8206-10,IR4000s,etc.		
L9438-50	VOLTAGE CORD	For 3193,3390,3390-10 (Black and red)		
L9438-53	VOLTAGE CORD	For 3169,3197 (Black,red,yellow and blue)		
L9438-55	VOLTAGE CORD	For 3197 (Black)		
L9635-01	VOLTAGE CORD	For 3286-20,3268		
L9787	TEST LEAD	For IR4000s,3154,3453,3454-10,-11,3490		
L9787-91	BREAKER PIN			
L9788-10	TEST LEAD WITH REMOTE SWITCH (RED)			
L9788-11	TEST LEAD SET WITH REMOTE SWITCH			
L9788-90	TIP PIN	For L9788		
L9788-92	BREAKER PIN			
L9790	CONNECTION CORD	For MR8847s,8870-20		
L9790-01	ALLIGATOR CLIP	For 8870-20,MR8847s		
L9820	CONNECTION CABLE	For FT3424		
L9840	AUXILIARY EARTHING ROD	For FT6031-03 (Standard)		
L9841	MEASUREMENT CABLE	For FT6031-03 (Standard)		
L9842-11	MEASUREMENT CABLE	For FT6031-03 (Standard)		
L9842-22e	MEASUREMENT CABLE	For FT6031-03 (Standard)		
L9844	MEASUREMENT CABLE	For FT6031-03 (Option)		
L9843-51	MEASUREMENT CABLE	For FT6031-03 (Option)		
L9843-52	MEASUREMENT CABLE	For FT6031-03 (Option)		
LR5001	HUMIDITY LOGGER			
LR5011	TEMPERATURE LOGGER	Temp. sensor shall be ordered separately.		
LR5031	INSTRUMENTATION LOGGER			
LR5041	VOLTAGE LOGGER (50mV)	With LR9802,50mV DC		
LR5042	VOLTAGE LOGGER (5V)	With LR9802,5V DC		
LR5043	VOLTAGE LOGGER (50V)	With LR9802,50V DC		
LR5051	CLAMP LOGGER	Clamp on sensor shall be ordered separately.		
LR5091	COMMUNICATION ADAPTER	For LR5000s		
LR5092-20	DATA COLLECTOR	For LR5000s		
LR8400-20	MEMORY HiLOGGER	With 2 x Voltage/Temp Unit LR8500		
LR8400-92	PV POWER VERIFIER			
LR8400-93	PV POWER VERIFIER			
LR8401-20	MEMORY HiLOGGER	With 2 x Universal Unit LR8501		
LR8402-20	MEMORY HiLOGGER	With 1 x LR8500 and 1 x LR8501		
LR8410-20	WIRELESS LOGGING STATION			
LR8431-20	MEMORY HiLOGGER			
LR8500	VOLTAGE/TEMP UNIT	For LR8400s,15ch		
LR8501	UNIVERSAL UNIT	For LR8400s,15ch		
LR8510	WIRELESS VOLTAGE/TEMP UNIT			
LR8511	WIRELESS UNIVERSAL UNIT			
LR8514	WIRELESS HUMIDITY LOGGER	Sensor sold separately		
LR8515	WIRELESS VOLTAGE/TEMP LOGGER			
LR8520	WIRELESS FUNGAL LOGGER	Sensor sold separately		
LR9501	HUMIDITY SENSOR	For LR5001,1m		
LR9502	HUMIDITY SENSOR	For LR5001,5m		
LR9503	HUMIDITY SENSOR	For LR5001,10m		
LR9504	HUMIDITY SENSOR	For LR5001,40mm		
LR9601	TEMPERATURE SENSOR	For LR5011,Molded plastic type,1m		
LR9602	TEMPERATURE SENSOR	For LR5011,Molded plastic type,5m		
LR9603	TEMPERATURE SENSOR	For LR5011,Molded plastic type,10m		
LR9604	TEMPERATURE SENSOR	For LR5011,Molded plastic type,45mm		
LR9611	TEMPERATURE SENSOR	For LR5011,Lug type,1m		

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
LR9612	TEMPERATURE SENSOR	For LR5011,Lug type,5m		
LR9613	TEMPERATURE SENSOR	For LR5011,Lug type,10m		
LR9621	TEMPERATURE SENSOR	For LR5011,Sheath type,1m		
LR9631	TEMPERATURE SENSOR	For LR5011,Needle type,1m		
LR9801	CONNECTION CABLE	For LR5031		
LR9802	CONNECTION CABLE	For LR5041-20,LR5042-20,LR5043-20,LR5061		
LR9901	WALL-MOUNTED HOLDER	For LR5000s		
MR8740	MEMORY HiCORDER			
MR8741	MEMORY HiCORDER			
MR8827	MEMORY HiCORDER			
MR8847-01	MEMORY HiCORDER	64MB Memory		
MR8847-02	MEMORY HiCORDER	256MB Memory		
MR8847-03	MEMORY HiCORDER	512MB Memory		
MR8875	MEMORY HiCORDER			
MR8880-20	MEMORY HiCORDER			
MR8901	ANALOG UNIT			
MR8902	VOLTAGE/TEMP UNIT			
MR8903	STRAIN UNIT			
MR8904	CAN UNIT			
MR8905	ANALOG UNIT	'Input cords are not included		
MR8990	DIGITAL VOLTMETER UNIT			
MR9000	PRINTER UNIT	For MR8880-20		
MR9321	LOGIC PROBE	For Memory recorders		
MR9321-01	LOGIC PROBE	For Memory recorders		
0GE00001				
0GE00002				
0GA00007				
0GA00008				
P-1201A	FELT PEN (RED)	For INR9000,etc.		
P-1202A	FELT PEN (GREEN)	For INR9000,etc.		
P-1203A	FELT PEN (BLUE)	For INR9000,etc.		
P9000-01	DIFFERENTIAL PROBE			
P9000-02	DIFFERENTIAL PROBE	With AC-RMS Output		
PD3129	PHASE DETECTOR			
PD3129-10	PHASE DETECTOR			
PR8111	PEN RECORDER	With 1 pen,P-1201A,SE-10Z-2,9418-15		
PR8112	PEN RECORDER	With 2 pens,P-1201A,-02A,SE-10Z-2,9418-15		
PW3198	POWER QUALITY ANALYZER	With L1000,Z1002,Z1003,Z4001,USB cable		
PW3198-90	POWER QUALITY ANALYZER	Supplied with 9624-50		
PW3335	POWER METER	With RS-232C		
PW3335-01	POWER METER	With GP-IB		
PW3335-02	POWER METER	With RS-232C, D/A		
PW3335-03	POWER METER	With RS-232C, Current Sensor input		
PW3335-04	POWER METER	With RS-232C, GP-IB, D/A,Current Sensor input		
PW3336	POWER METER	2ch		
PW3336-01	POWER METER	2ch, with GP-IB		
PW3336-02	POWER METER	2ch, with D/A Output		
PW3336-03	POWER METER	2ch, with GP-IB and D/A Output		
PW3337	POWER METER	3ch		
PW3337-01	POWER METER	3ch, with GP-IB		
PW3337-02	POWER METER	3ch, with D/A Output		
PW3337-03	POWER METER	3ch, with GP-IB and D/A Output		
PW3360-20	CLAMP ON POWER LOGGER			
PW3360-21	CLAMP ON POWER LOGGER	With Harmonics Measurement		
PW3365-20	CLAMP ON POWER LOGGER			
PW6001-01	POWER ANALYZER	1ch		
PW6001-02	POWER ANALYZER	2ch		
PW6001-03	POWER ANALYZER	3ch		
PW6001-04	POWER ANALYZER	4ch		
PW6001-05	POWER ANALYZER	5ch		
PW6001-06	POWER ANALYZER	6ch		

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
PW6001-11	POWER ANALYZER	1ch w/Motor & D/A option		
PW6001-12	POWER ANALYZER	2ch w/Motor & D/A option		
PW6001-13	POWER ANALYZER	3ch w/Motor & D/A option		
PW6001-14	POWER ANALYZER	4ch w/Motor & D/A option		
PW6001-15	POWER ANALYZER	5ch w/Motor & D/A option		
PW6001-16	POWER ANALYZER	6ch w/Motor & D/A option		
PW9000	WIRING ADAPTER	For 3196,PW3198,3P3W		
PW9001	WIRING ADAPTER	For 3196,PW3198,3P4W		
PW9002	BATTERY SET	For PW3360-20		
PW9003	VOLTAGE LINE POWER ADAPTER	For PW3360-20		
PW9005	GPS BOX	For PW3198		
PW9020	SAFETY VOLTAGE SENSOR	For PW3365-20		
RM3542	RESISTANCE HiTESTER			
RM3542-01	RESISTANCE HiTESTER	With GP-IB		
RM3543	RESISTANCE HiTESTER			
RM3543-01	RESISTANCE HiTESTER			
RM3544	RESISTANCE METER			
RM3544-01	RESISTANCE METER			
RM3545	RESISTANCE METER			
RM3545-01	RESISTANCE METER	with GP-IB		
RM3545-02	RESISTANCE METER	Supports use of the Z3003		
RM3548	RESISTANCE METER			
SE-10	RECORDING PAPER	For EPR-10B,10 rolls		
SE-10Z-2	RECORDING PAPER	For EPR-10B,10 rolls		
SF1001	POWER LOGGER VIEWER	For PW3360-20, 3169s		
SM9001	SURFACE/VOLUME RESISTANCE MEASUREMENT ELECTRODE			
SM9002	VERIFICATION FIXTURE FOR SURFACE RESISTANCE MEASUREMENT			
SM-8213				
SM-8215				
SM-8220				
SM-7810				
SME-8301				
SME-8302				
SME-8310				
SME-8311				
SME-8320				
SME-8330				
SME-8360				
SME-8350				
SR-2				
SS7012	DC SIGNAL SOURCE			
SS9000	COMMUNICATION PACKAGE	For SS7012		
ST5520	INSULATION TESTER	External I/O output		
ST5520-01	INSULATION TESTER	BCD Output		
ST5540	LEAK CURRENT HiTESTER	With Network B		
ST5541	LEAK CURRENT HiTESTER	Without Network B		
U8330	SSD UNIT	For MR8827/Factory Option		
U8350	PRINTER UNIT	For MR8827/Factory Option		
Z1000	BATTERY PACK	For LR8400s,MR8880-20,MR8880-21		
Z1002	AC ADAPTER	For PW3198,MR8880-20		
Z1003	BATTERY PACK	For MR8875,PW3198		
Z1004	AC ADAPTER	For FT3405,FT3406		
Z1005	AC ADAPTER	For 8430-20,8870-20		
Z1006	AC ADAPTER	For PW3360-20		
Z1007	BATTERY PACK	Li-ion Battery		
Z1008	AC ADAPTER			
Z1009	FIXED STAND			
Z1012	AC ADAPTER			
Z2000	HUMIDITY SENSOR	For LR8400s		
Z2001	TEMPERATURE SENSOR	For RM3544s, RM3545x		
Z2002	TEMPERATURE SENSOR	For RM3548		

Model	Description	Supplement	Склад СПб, руб. без НДС	Склад СПб, руб. с НДС
Z2010	HUMIDITY SENSOR			
Z2011	HUMIDITY SENSOR			
Z3000	GP-IB INTERFACE	For IM3523,IM3533,IM3533-01,IM3590		
Z3001	RS-232C INTERFACE	For IM3523,IM3533,IM3533-01,IM3590		
Z3002	LAN INTERFACE	For IM3523,IM3533,IM3533-01,IM3590		
Z3003	MULTIPLEXER UNIT			
Z4001	SD MEMORY CARD 2GB	For PW3198,LR5092-20		
Z5000	FIXED STAND	For LR8400s		
Z5003	CONTACT ADAPTER	For FT3405,FT3406		
Z5004	MAGNETIC STRAP	For LR5000s		

РАДАР - ОФИЦИАЛЬНЫЙ ДИЛЕР НЮКИ



РОССИЯ, 198152, Санкт-Петербург  
Краснопутиловская ул., д.25  
Тел./факс +7 (812) 600-48-89  
Тел.: +7 (812) 375-32-44  
[www.radar1.ru](http://www.radar1.ru)  
[info@radar1.ru](mailto:info@radar1.ru)

**Прайс НЮКИ, цена НЮКИ пополняется !**